




LA-83-ARCUS


6








Standard Mounting



BRIDGE 1.5Kw /1.85Kw Boost



256


133

	800m³/hr Brushless Motor		
	Speed 1	Speed 9	Boost
Extraction Rate	220m³/hr	450m³/hr	620m³/hr
Noise Levels DB/A	44 DB	63DB	69DB

80 - 160

Extraction Area






The new shape ensures that the dropped water will always be directed to the emptying system.



INTERNAL PART OF THE PLASTIC CASE – EASY TO CLEAN




Bottom part

Grease Filters




EXTRACTOR – GRID








Using the same grid for both dimensions (80 and 60 cm)



- Aluminium,
- Painted aluminium,
- Glass
- Wooden
- Stainlees steel or painted.







For easy mantenaince, it's possible to remove grid and filter togheter


Grease Filters



HOB EXTRACTOR – GREASE FILTER




Water collectors (0,3 L)




Charcoal Filters

HOB EXTRACTOR – RECIRCULATION VERSION OPTION 1





NEW OPTION : a regenerable filter – LONG LIFE - can be installed from the suction area. Remove the grid and grease filter and you can install it. All maintenance operations are much simpler.





Long Life STARTER KIT





Plastic + long life to add and cover the bottom part of the filter

Only 2 steps to access the filters

Instruction:

- Remove the grid and the filter together,
- Remove the long life filter,
- Follow the procedure to regenerate the filter (dishwasher and oven).

Installation

HOB EXTRACTOR – INSTALLATION

